



## Timbakote Rustic Coatings Easy Spec

### DESCRIPTION

Timbakote Rustic coatings are tough acrylic water based coatings designed for New Zealand's harsh conditions, gives excellent adhesion to all timber, fibre cement and concrete substrates. Timbakote is environmentally friendly, and approved by Environmental Choice N Z.

### RECOMMENDED USES

**Timbakote Rustic Coatings** is an ideal finish for all exterior bandsaw timber, textured fibre cement weatherboards and rough cast concrete.

### SURFACE PREPARATION

**New Timber** should be clean and dry, free of any loose fibres. Sharp edges **must** be sanded, nail holes and minor defects to be filled with suitable quality timber filler

**Exposed Timber** (greater than one week), remove any contamination; loose timber fibres and treat with a solution of Sugar Soap. Complete as per new timber.

**Previously oiled or stained timber:** remove all poor adhering coatings, sand and treat with a solution of Sugar Soap . Complete as per new timber.

**Fibre Cement Weatherboards and Concrete** Should be clean and surfaces dry, free from contaminants.

### APPLICATION

Stir well before and during use with a flat stirrer. Apply 1 coat **Timbakote Rustic Basecoat** with a good quality paintbrush, applicator pad, roller or spray.

Thinning is not generally recommended, as it can be detrimental to the coating performance. The addition of 50mils of water per Litre maybe required in hot weather or when coating absorbent surfaces.

Allow up to 2 hours for Timbakote Rusticated Basecoat to dry then apply **2-3 coats of Timbakote Rustic Exterior Timber Finish** to achieve the desired Rustic Timber effect. Do not over spread, as achieving the correct film build is important to the life of semi-transparent coatings.

### COVERAGE

Timber Band Sawn	4 - 10 sqm per Litre
Timber Dressed	7 – 12 sqm per Litre
Fibre Cement Weatherboards	7 - 12 sqm per Litre

### DRYING TIMES

Depending on such factors as film thickness, ambient air temperatures, humidity levels and air circulation. The general dry times at 6-12 sq metres per Litre are: Touch dry 20 minutes – Recoat time 2 hrs – Curing time 7 days.

### CLEAN UP

All equipment can be cleaned up in water.

### SAFETY

Wear impervious gloves and wash paint deposits off skin with soap and water.

Moderately irritating to eyes- wear splash proof goggles to protect eyes. Flush eyes immediately with plenty of water if coating splashes to the eyes occur. If discomfort persists seek medical attention. Keep out of children's reach. Ingestion; Give 1-3 cups of water and seek medical attention.

### DISPOSAL

Let residual coating dry by leaving the lid off the container. Dispose with refuse if permitted by local council. Paint containers are reusable for non-food purposes and recyclable in areas where recycling and collection facilities are available.

**See Product Data Sheet for full details.**

Every care is taken to ensure that the information provided in this data sheet is accurate. Timbakote Ltd is unable to guarantee results as it has no control over the conditions under which products are applied, the substrate or the application. The customer has to determine the suitability of the delivered products or information for its intended purpose.