



Timbakote® Rustic Timber Finish Shadowclad® – Climate® Primed Easy Spec

DESCRIPTION

Timbakote® Rustic Timber Finish is a semi-transparent water based 100% acrylic coating that protects from the weather and harsh Ultra Violet (uv) rays, and enhances the natural beauty of Shadowclad® - Climate® Primed Ply sheeting

Timbakote complies and is licensed by Environmental Choice New Zealand.

RECOMMENDED USE

Timbakote® Rustic Timber Finish is an ideal finish for Shadowclad® - Climate® Primed sheets where a long lasting stained timber effect is required.

SURFACE PREPARATION

Surface should be clean and dry, stains, and any stencils or other marks should be removed. Nail holes and minor defects to be filled with suitable timber filler, sanded and dusted. All cut edges need to be sealed prior to installation. If cladding has been left exposed for longer than 30 days, wash down prior to application with a water hose and soft broom to remove any contamination.

APPLICATION

Stir well before and during use with a flat stirrer. Apply 2 - 3 generous coats of Timbakote® Rustic Timber Finish with a good quality paintbrush, applicator pad, roller or spray. If spraying, lay off with an applicator pad, brush or roller to provide an even appearance. Do not over spread. **Achieving the correct paint film thickness is important to the life of a semi-transparent coating.** Apply Timbakote® Rustic Timber Finish to one sheet at a time; lay off in long even strokes along the sheets length working to natural breaks. Always keep a wet edge to avoid lap marking. **Highly exposed aspects require an additional coat for extra protection due to extreme weathering.** Apply the final coat of Timbakote® Rustic Timber Finish **after** the cladding has being fixed to the wall. Pay particular attention to the grooves.

If using more than one container of Timbakote® make sure all containers are mixed together prior to application. Thinning is not generally recommended, as it can be detrimental to the coating performance. The addition of 50mils of water may be required in hot weather.

Use colours with a light reflectance value of 40% or more to meet the 50-year durability requirement of the NZBC.

COVERAGE

7 – 14 sq metres per Litre. Depending on temperature and application technique.

DRYING TIMES

Depending on such factors as film thickness, ambient air temperatures, humidity levels and air circulation. The general dry times at 6-12 sq metres per Litre are: Touch dry 20 minutes – Recoat time 2 hrs – Cure time 7 days.

CLEAN UP

All equipment can be cleaned up in water.

SAFETY

Wear impervious gloves and wash paint deposits off skin with soap and water.

Moderately irritating to eyes - wear splash proof goggles to protect eyes. Flush eyes immediately with plenty of water if coating splashes to the eyes occur. If discomfort persists seek medical attention. Keep out of children's reach. Ingestion; Give 1-3 cups of water and seek medical attention. VOCs 6 grams per Litre.

DISPOSAL

Let residual coating dry by leaving the lid off the container. Dispose with refuse if permitted by local council. Paint containers are reusable for non-food purposes and recyclable in areas where recycling and collection facilities are available.

See Product Data Sheet for full details

Every care is taken to ensure that the information provided in this data sheet is accurate. Timbakote® Ltd is unable to guarantee results as it has no control over the conditions under which products are applied, the substrate or the application. The customer has to determine the suitability of the delivered products or information for its intended purpose.